ERSATZTEILLISTE
OKIFAX OF-10

SPARE PARTS LIST
OKIFAX OF-10

M-OSD-10051-10

ÜBERBLICK (OVERVIEW)



ZEICHNUNG 1 - CABINET AND PCB ASSY (FIGURE 1 - CABINET AND PCB ASSY)



LISTE 1 - CABINET AND PCB ASSY (TABLE 1 - CABINET AND PCB ASSY)

NR. NO.	BEZEICHNUNG PART NAME	BESTELL-NR. PART NO
1	REAR COVER	4PP3512-3085P1
5	CONNECTOR CAP	3PP3512-3025P1
6	SCREW	+D3-6-F
7	TERMINAL CAP	3PP3512-3044P1
10	PC BOARD, NCU26	4YU3512-1051G3
11	PC BOARD ROM/RAM-10	4YU3512-1133G3
13	RUBBER FOOT	4PP3512-3106P1
15	STAY	TM-28-I-CR(5011)
17	SCREW	+D4-8-F
19	FRONT COVER	1PP3512-3004P2
20	PCB (MCNT-10)	4YU3512-1131G2
21	PCB (ENC/DEC-10)	4YU3512-1134G1
22	MODEM PCB	4YA1036-1321G1
24	OPERATION PANEL ASSY	1PA3512-3434G3
25	MODEM BRACKET	4PP3512-3103P1
26	COPY STACKER	4PA3512-3415G1
27	DOCUMENT STACKER ASSY (ENTHÄLT NR. 28,29)	3PA3512-3138G1
33	MODEM BRACKET (R)	4PP3512-3157P1
34	SIDE RIGHT COVER ASSY (ENTHÄLT NR. 3, 4)	3PA3512-3192G1
38	MIRROR CLEANING BRUSH	3PP3512-3245G1

ZEICHNUNG 2 - CONTROL PANEL ASSY (FIGURE 2 - CONTROL PANEL ASSY)



LISTE 2 - CONTROL PANEL ASSY (TABLE 2 - CONTROL PANEL ASSY)

NR. NO.	BEZEICHNUNG PART NAME	BESTELL-NR. PART NO
1	PANEL CARD COVER	4PP3512-3208P1
2	PANEL CARD	3PP3512-3209P3
11	PCB (OPE-10)	4YU3512-1132G1
15	OPERATION PANEL ASSY (ENTHÄLT NR. 1 - 14)	1PA3512-3434G3

ZEICHNUNG 3 - DOCUMENT DRIVE ASSY (FIGURE 3 - DOCUMENT DRIVE ASSY)



LISTE 3 - DOCUMENT DRIVE ASSY (TABLE 3 - DOCUMENT DRIVE ASSY)

NR. **NO.**	**BEZEICHNUNG** **PART NAME**	**BESTELL-NR.** **PART NO**
1	BOTTOM FEED ROLLER ASSY (ENTHÄLT NR. 4,9,43,44)	3PA3512-3136G1
2	TOP FEED ROLLER ASSY (ENTHÄLT NR. 3,4,41,42)	3PA3512-3135G1
5	ADF ROLLER ASSY (ENTHÄLT NR. 4,6-11,39,40)	3PA3512-3133G1
13	SOLENOID	273A1150P0001
15	SUB ROLLER ASSY (ENTHÄLT NR. 16-20)	3PA3512-3134G1
23	SCAN DRIVE MOTOR	272A1170P0001
24	PULLEY (Z17)	NA3182-1508G1
25	CUTTER DRIVE BELT	152A1030P0016
27	ADJUSTMENT IDLER	4PP3512-3028P1
28	DOCUMENT FEED BELT	152A1030P0016
29	PULLEY (Z33/17)	4PP3512-3032P1
30	IDLE BRACKET	4PP3512-3149P1
31	SCREW	+TP3-10-HHC
35	PHOTO SENSOR	652A0130M0004
37	DOCUMENT GUIDE	2PP3512-3009P2
40	ADF ROLLER	NA3201-1130G1
42	FEED TOP ROLLER	3PP3512-3049P1
43	ONE WAY PULLEY (Z17)	4PP3512-3030P1

ZEICHNUNG 3- DOCUMENT DRIVE (FIGURE 3 - DOCUMENT DRIVE)

DETAIL A - PAPER GUIDE (D) ASSY



LISTE 3 - DOCUMENT DRIVE (TABLE 3 - DOCUMENT DRIVE)

DETAIL A - PAPER GUIDE (D) ASSY

NR. NO.	BEZEICHNUNG PART NAME	BESTELL-NR. PART NO
3	PHOTO SENSOR	652A0130M0004
4	SCAN ACTUATOR	4PP3512-3036P1
7	PINCH ROLLER GUIDE	2PP3512-3010P1
8	ADF MYLAR	4PP3512-3096P1
9	PLATE SPRING	4PP3512-3082P1
10	SEPARATION RUBBER	4PP3512-3095P1
14	PINCH ROLLER	4PP3512-3046P1
15	DOCUMENT ACTUATOR	4PP3512-3035P1
16	BACK-UP BRACKET	3PP3512-3019P1
17	PRESSURE BAR	4PP3512-3037P1
19	PINCH ROLLER GUIDE	4PP3512-3018P1
20	PINCH ROLLER SPRING	4PP3512-3079P1
24	EARTH BRUSH	4PP3512-3143P1
25	PINCH RELEASE BUTTON	3PP3512-3020P1
27	WIRE CLAMPER	123A1120P0002
28	SIDE COVER ASSY, L (ENTHÄLT NR. 1, 2, 24)	3PA3512-3351G6
29	SEPARATION RUBBER ASSY (ENTHÄLT NR. 8,10)	4PA3512-3170G1

ZEICHNUNG 4 - SCAN ASSY (FIGURE 4 - SCAN ASSY)



LISTE 4 - SCAN ASSY (TABLE 4 - SCAN ASSY)

NR. NO.	BEZEICHNUNG PART NAME	BESTELL-NR. PART NO
1	MIRROR	NA3201-1039P1
2	MIRROR SPRING	4PP3512-3063P1
4	SCAN ASSY (ENTHÄLT NR. 5-20)	2PA3512-3168G2
24	F. L. SOCKET BRACKET	4PP3512-3065P1
26	CABLE W8	4YS3512-1027P1
27	FLUORESCENT LAMP BRACKET	3PP3512-3072P1
28	FLUORESCENT LAMP	4YB3512-1087P1

ZEICHNUNG 5 - PRINTING AND PAPER DRIVE ASSY
(FIGURE 5 - PRINTING AND PAPER DRIVE ASSY)



LISTE 5 - PRINTING AND PAPER DRIVE ASSY (TABLE 5 - PRINTING AND PAPER DRIVE ASSY)

NR. **NO.**	**BEZEICHNUNG** **PART NAME**	**BESTELL-NR.** **PART NO**
1	PAPER COMPARTMENT COVER	3PP3512-3278P1
2	PRINT ROLLER ASSY (ENTHÄLT NR. 3, 5-7)	3PA3512-3132G1
3	PRINT ROLLER PULLEY (Z45)	NA3201-1106P1
4	PAPER DRIVE BELT	152A1030P0017
22	SLIP SHEET	NA3201-1178P2
24	SET SCREW	140A1090P0002
26	PULLEY (Z17)	NA3182-1508G1
27	PRINT DRIVE MOTOR	272A1024P0001
30	MICRO SWITCH	SM114S
36	MICRO SWITCH	207A1027P0001
37	EXIT LOWER GUIDE	3PP3512-3069P1
38	EARTH BRUSH	4PP3512-3143P1
39	CUTTER UNIT	4YB3512-1041P2
41	MICRO SWITCH ASSY	4PA3512-3349G1
45	PAPER END DETECTOR	4AA3512-3078G1
46	SWITCH BRACKET	3PP3512-3016P1
48	PAPER ROLLER ALIGNER	3PP3512-3022P1
50	CUTTER UNIT ASSY (ENTHÄLT NR. 38-40)	4YB3512-1375G4
51	STOPPER BRACKET	4PP3512-3311G1

ZEICHNUNG 6 - PRINTING AND PAPER DRIVE ASSY
(FIGURE 6 - PRINTING AND PAPER DRIVE ASSY)

DETAL A: PAPER COMPARTMENT ASSY



LISTE 6 - PRINTING AND PAPER DRIVE ASSY (TABLE 6 - PRINTING AND PAPER DRIVE ASSY

DETAIL A: PAPER COMPARTMENT ASSY

NR. NO.	BEZEICHNUNG PART NAME	BESTELL-NR. PART NO
15	OVER HEAT LABEL	4PP3512-3275P2
20	MICRO SWITCH	207A1027P0001
21	PINION GEAR	NA3201-1073P1
28	PAPER COMPARTMENT SUB ASSY (ENTHÄLT NR. 2,11,23,25-27)	3PA3512-3282G2
29	THERMAL HEAD ASSY (ENTHÄLT NR. 14-16,30-32)	3PA3512-3357G1

ZEICHNUNG 7 - POWER SUPPLY UNIT (FIGURE 7 - POWER SUPPLY UNIT)



LISTE 7 - POWER SUPPLY UNIT (TABLE 7 - POWER SUPPLY UNIT)

NR. **NO.**	**BEZEICHNUNG** **PART NAME**	**BESTELL-NR.** **PART NO**
1	POWER SUPPLY UNIT, NW	4YB3512-1199G3
	POWER SUPPLY UNIT, DTW	4YB3512-1199G4
2	POWER SUPPLY UNIT BRACKET	4PP3512-3104P1